

# LDP1602 LCD Module

*Snap-on module for the ioLogik 2000 and ioMirror 3000 series*



- > Hot-pluggable display module for ioLogik Active Ethernet I/O, serial I/O, and Peer-to-Peer I/O
- > Easy, portable configuration kit for IP display and configuration
- > Direct display for analog value and digital input, counter status
- > No battery required (powered through the I/O )

The certification logos shown here apply to some or all of the products in this section. For details, see "Regulatory Approvals" under "Specifications" below.



## Installing the LCD Module

1. Remove the ioLogik's top cover.



2. Plug in the LCD module.



3. Check and configure the IP address.



4. Check IP and I/O status.



## Specifications

**LCD Screen:** 16 x 2 text display (in English)  
**Operating Temperature:** 0 to 55°C (32 to 131°F)

**Storage Temperature:** -20 to 70°C (-4 to 158°F)  
**Ambient Relative Humidity:** 5 to 95% (non-condensing)

## Ordering Information

**LDP1602:** LCD module with 16 x 2 text display and 5 buttons